



If thermostat display does not turn on (illuminate), swap the positions of the red and white wires.

